

CRAWLTEK R E V O L U T I O N

491 W. GARFIELD AVE., COLDWATER, MI 49036 • 517.278.1039
CRAWLTEKREVOLUTION.COM • E-MAIL: SALES-CRAWLTEK@RIDEFOX.COM

INSTALLATION INSTRUCTIONS

FAIRLEAD LIGHT MOUNT

CT11001

UNIVERSAL



CrawlTek YouTube

PLEASE READ THROUGH INSTRUCTIONS BEFORE INSTALLING

2020-11-24

WHAT'S IN THE BOX?

PLEASE VERIFY KIT CONTENTS BEFORE BEGINNING INSTALLATION

PART #	Qty	DESCRIPTION
06175	1	UNIVERSAL FAIRLEAD LIGHT MOUNT
CWLU30010	1	DECAL: CRAWLTEK GEARSHIFT 3.5" X 3.5"
CWLU30020	1	DECAL: CRAWLTEK EYES 6" X 2"
CWLU30030	1	DECAL: CRAWLTEK JAX 3.75" X 2.8"
	1	TAMPER-RESISTANT T40 TORX BIT, 1/4" HEX SHANK
	3	M8-1.25 X 16 MM TAMPER-RESISTANT BUTTON HEAD TORX SCREWS
	3	M8 PLASTIC WASHER, 8.4MM ID, 18MM OD
	3	M8-1.25 NYLOCK, CLEAR ZINC

TOOLS REQUIRED

3/16" ALLEN WRENCH OR SOCKET
WIRE CUTTERS/ STRIPPERS
WIRE CRIMPERS
HEAT GUN

NOTES

- FAIRLEAD MOUNT CAN BE REVERSED DEPENDING ON THE BUMPER AND HOW MUCH ROOM YOU HAVE)
- DESIGNED TO FIT 1 10" LIGHT BAR, OR 2 - 3 SINGLE LIGHTS.

INSTALLATION

STEP 1:

REMOVE FAIRLEAD IF ALREADY INSTALLED

STEP 2:

INSTALL FAIRLEAD BRACKET BEHIND FAIRLEAD (DEPENDING ON YOUR BUMPER YOU CAN INSTALL THE BRACKET EITHER FORWARD OR BACKWARDS)

STEP 3:

INSTALL LIGHTS.





YOU'RE NOT DONE YET!

Thank you for your new CrawlTek Revolution purchase! Follow us on facebook for up to date coverage of new product releases. We love feedback, if you have any questions about the installation or parts were missing please contact us at sales-crawltek@ridefox.com or call us at 517.278.1039.

Be sure to show off your jeep to the rest of the CrawlTek Revolution online. Find us on facebook and instagram to keep up on new products, upcoming events and more action. Tag us @crawltek for a chance to get featured

