



INSTALLATION INSTRUCTIONS

PART No.

FB21398

**Ford 04-14 F-150/Raptor
Hood Pod Light Brackets**



REQUIRED TOOLS

10mm Socket

Help of a Friend

KIT CONTAINS

Hood Bracket (Driver/Passenger)

QTY

1ea

2139800

1) OPEN & INSTALL

Open your vehicle's hood and remove the two bolts from your hinge. Have your friend support the hood & only install one side at a time. With a 10mm socket, remove the bolts.



Place the side specific bracket onto the top of the hinge, and secure it by reusing the factory hardware.



Repeat on the opposite side.

Close the hood and install your pod lights of choice.

