



INSTALLATION INSTRUCTIONS

PART No.

FB22364

**15-20 Ford F-150
Pelican Rear Bumper**



VIDEO AVAILABLE



REQUIRED TOOLS

21mm Socket
13mm Socket
13mm Wrench
Pliers
10mm Socket
10mm Wrench

Help of a Friend

KIT CONTAINS

Pelican Rear Bumper
D-Rings
M6 Hex Bolt
M6 Washer
M6 Hex Nut
M6 Lock Washer

QTY

1
2

2236400

1) UNINSTALL FACTORY BUMPER

With a 21mm, remove the 3 hex nuts on each side of the frame rails.



Disconnect your hitch plug and license plate lights, and with a clip remover tool, free the power harness from the bumper.



Remove the bumper. With a 13mm socket, remove your hitch retaining plates and hitch.



Push out and remove the license plate lights and hitch plug.



2) REINSTALL HITCH

With 4 of the 6 factory bolts remove in Step 1, reinstall the hitch onto the frame with a 21mm socket.



With pliers, bend the two angled flanges straight and flat.



3) INSTALL LIGHTS, HITCH PLUG, AND POWER HARNESS



4) INSTALL BUMPER

With the help of a friend, hold the bumper up to the frame. With the included hardware, secure it to the hitch with a 10mm socket and wrench. Reconnect your power harness

