

INSTALLATION INSTRUCTIONS

PART No.

2015-2017 Ford F150 Pelican Front Bumper

QTY

FB22365





REQUIRED TOOLS

7mm Socket 8mm Socket 10mm Socket 15mm Socket 18mm Socket 18mm Wrench 21mm Socket Clip Remover Tool

Help of a friend

KIT CONTAINS

Front Bumper	1
D-Ring	2
Mounting Plate	1
M12 Hex Bolt	6
M12 Flange Nut	6

2236500



INSTALLATION INSTRUCTIONS

PART No.

2015-2017 Ford F150 Pelican Front Bumper

FB22365

1) REMOVE EXISTING BUMPER

Begin removing your vehicle's existing front bumper. Start by disconnecting your battery with a 10mm socket, and any accessories connected to your grille.



Followed by removing the body clips above your grille and headlights with a clip remover tool.



With a 7mm socket, remove the two bolts in the wheel well just behind each headlight.



Begin gently prying at the headlight trims, revealing a bolt. Remove this bolt with an 8mm socket.





The factory bumper can be separated into 3 parts: Cover, outer shell, and inner brackets. Remove the out cover by gently and evenly pulling it away, exposing the frame rails. Followed by disconnecting the fog lights.



2236500

550 W. PINE LAKE RD., SUITE 2, NORTH LIMA, OHIO 44452 330.423.6446 WWW.FISHBONEOFFROAD.COM

1



INSTALLATION INSTRUCTIONS

PART No.

2015-2017 Ford F150 Pelican Front Bumper

FB22365

Underneath the vehicle, behind the outer shell on each side, remove the flange nut with a 21mm socket, followed by the 2 nuts on the front of the frame rails, releasing the bumper.



Remove each recovery hook with a 15mm socket.

2) INSTALLL

Install the winch bracket onto the frame rails with all of the factory hardware.



Install any winch, light pods, or bars at this time.

With the help of a friend, lift the bumper up to the frame and secure it to the winch plate with the included hardware and an 18mm socket and wrench.



Reinstall your headlight trim, body clips, and battery.



2