



# INSTALLATION INSTRUCTIONS

Product: Rear Lower Strut Mount Skid Plate Kit  
Part Number: JKS8308

Applications: 2021 Ford Bronco

517-278-1226 • jkstech@ridefox.com • www.jksmfg.com  
491 W. Garfield Avenue, Coldwater, MI 49036

## Welcome

CONGRATULATIONS on purchasing this rear lower strut mount skid plate kit from JKS Manufacturing. We are committed to providing you with the best products available and your satisfaction is our first priority.

PLEASE READ these Installation Instructions carefully, and save them for future reference, as they contain important installation and maintenance information.

## Important

*Designed to be used with models of the Bronco which use the yellow Bilstein struts. Badlands, Wildtrak and First Edition or Sasquatch packages use these shocks. If your model has the black Hitachi struts reference kit JKS8309*

## Tools Required

- Hydraulic Floor Jack and Jack Stands
- 27mm Metric Socket
- 30mm Metric Socket & Wrench
- 9/16" Socket & Wrench
- Rivet Tool
- Torque Wrench

## Parts

	Description	QTY
<b>A</b>	Strut Mount Skid Plate - DRV (07003)	1
<b>B</b>	Strut Mount Skid Plate- PASS (07004)	1
<b>C</b>	Mounting Bolt Pack (J168)	1
<b>D</b>	Badge Rivet Bolt Pack (887)	1
<b>E</b>	JKS Badge (03280)	2


## Installation Instructions

### 1. DISSASSEMBLY

- Park vehicle on clean, flat, and level surface. Block the front wheels from moving.
- Raise the rear of the vehicle and place jack stands under the frame rails. Lower the vehicle onto the jack stands. Be sure to have your stands high enough that the axle is at full droop (tires off the ground).

**NOTE:** *It is important that the strut is not being compressed at all to allow you to remove the lower bolt safely.*

- Remove the rear wheels / tires from the vehicle.
- Working on one side at a time, use a 27mm socket to remove the lower strut mounting bolt. Discard this bolt and nut.



## 2. INSTALLATION

- Once factory bolt is removed the strut will pull towards the rear of the vehicle. You will need to have a friend help hold the strut forward to keep the holes lined up while installing your skid plate.

**NOTE:** If you are doing this install by yourself you can hook a strap to one of the lower windings of the coil spring and the frame to pull it forward and get the holes aligned while installing.



- While the strut is held forward for the hole to align, slide the skid plate over the mounting bracket and install 2 of the provided M20 washers from bolt pack J168 (one on each side) between the skid plate and factory bracket as shown below.



- Once the skid plate is in place install the provided M20 x 160 bolt washers, and nylock nut (Bolt pack J168) in the lower strut mount with the head of the bolt towards the center of the vehicle. DO NOT tighten at this time.
- After the main bolt is in, locate your 3/8" bolt, nut, and washers. Swivel your skid plate until the small hole on the inside face lines up with the factory hole on the factory bracket. Install the provided 3/8" bolt, washers and nut as shown below. Torque to 30 ft-lbs.



- Using the JKS badges and the supplied rivets in bolt pack 887 install the JKS badges on the rear of your skid plates as shown below.



- Repeat installation process on opposite side of vehicle.
- Once both skid plates have been installed install wheels and torque lug nuts to 100 ft-lbs.
- After the vehicle is on the ground, then use a 30mm socket and wrench to torque the main mounting bolts to 350 ft-lbs.

## Maintenance

Recheck hardware after 500 miles.

©2022 JKS Manufacturing, Inc & Aftermarketing, LLC  
Revision Date 08/08/2022